

# BLOC 11

Ref: 41.70521.00 XXX XXX

## **User Manuel & Troubleshooting Guide**



Acknowledgement	P.2
Safety Warnings	P.2
Accessories / Associated references	P.2
Equipment description	P.2
Technical characteristics	P.3
Electrical characteristics	P.3
Description of the markings used	P.3
Installation instructions	P.5
Connection	P.5
Wiring	P.6
Terms and conditions	P.7
Warranty terms	P.7





### Acknowledgement

We thank you for your purchase and hope that you are fully satisfied with this product.

Before you use this product, we recommend you read the instructions below carefully. This manual explains how to use and install the product in accordance with its intended use.

### **Safety Warnings**

#### **WARNING: Do not disassemble the device**

Any contact with the product's internal components can cause injury. In the event of a malfunction, only a qualified technician is authorised to repair the device

### **WARNING: In the event of impact**

If the product falls or undergoes heavy impact, immediately contact a qualified person to ensure the device is working correctly

### **WARNING: Unpacking the equipment**

After unpacking the product, make sure that it is complete and in good condition. If you are not sure, immediately contact a person with the required professional qualification

### **WARNING: Unpacking the equipment**

Do not leave any part of the packaging within the reach of children or vulnerable adults

### Accessories / Associated references

Designation	Reference
120Ω BUS CAN Termination	0D.CRD399
Crimp contacts and 21-point MCP connector	62.SAC12003A.00

### **Equipment description**

Bloc 11 is used to interface 6 momentary switches or contacts. Status information is available via a potential-free relay contact.

It interfaces with a Scheiber Multibloc network, in order to recover the state of the control switch and to deport the control to a power block (Bloc 9 for example).



### Technical characteristics

	BLOC 11
REFERENCE	41.70521.00 XXX XXX
POWER SUPPLY	8-32 V DC
DETAILS AND FEATURES OF THE INPUTS	6 plus digital inputs
DETAILS AND FEATURES OF THE OUTPUTS	6 relay outputs 1A potential free (32V max.)
CAN BUS	2 x connectors type 6-way Micro-Fit
ENVIRONMENTAL CONDITIONS	Indoor use Altitude up to 2000m Operating temperature: 0 to +50 °C Relative humidity: 0 to 93% - non-condensing Protection index: IP20
MOUNTING	4 screws
MOUNTING DISTANCE	100 x 59 mm
WEIGHT	0,19 Kg
STANDARDS	EN 60945
FIRMWARE VERSION	V8.00 or higher
DIMENSIONS (LxWxH)	160 x 95 x 50 mm

### Electrical characteristics


INPUT RATED VOLTAGE (VDC)	8-32 VDC
SELF-CONSUMPTION	45 mA
MAXIMUM CURRENT PER OUTPUT	1A
MAXIMUM CUMULATIVE CURRENT	5A

## Description of the markings used


V	Volt
Α	Ampere
ou DC	Direct current




## **Seen from above**



### **Left side view**



## Right side view



### **Installation instructions**




- This device must be placed in a place protecting it from any risk of water splashing. Install in a ventilated location
- Do not install on supports that are sensitive to heat, such as carpet or PVC flooring, etc.
- The product must be installed away from heat and humidity





WARNING: Connection/disconnection with power on

Do not perform connection or disconnection with power on.

#### Mounting







Mounting distance: 100 x 59 mm

### Connection

### INPUT / OUTPUT / POWER SUPPLY

Type of connection

**Cross section** 

MCP2,8 - 21Pts (BROWN) housing connectors Ref. Scheiber 0E.CON1430 Ref. Tyco 8-968975-1 MCP2,8GEH21P

MCP2,8 Receptacle 0,5-1,0mm2 tinned Ref. Scheiber 0E.CLP360 Ref. Tyco 1-968849-1


Extraction tool for MCP contacts Réf. Tyco 1-1579007-2

### **CAN BUS**

2 x CAN connectors type 6-way Micro-Fit

### PROTECTION TO BE PROVIDED ON THE SUPPLY LINE


Protection rating Protection location Fuse or circuit breaker 5A Accessible and identified for the user





## Wiring

- 1 Connect to each connector:
  - either a CAN connection cable (to another Multibloc compatible device)
  - or a  $120\Omega$  impedance matching plug.



(2) Connect the equipment to the pins according to the numbering available in the table below, then plug the MPC connector into the TYCO receptacle.



crimp pins x21 MCP connector TYCO receptacle

Crimp pin	Designation	Description
1	S1_NO	NO Contact Relay n°1
2	S1_C	Common relay contact n°1
3	E1_NUM_PLUS	Plus digital input for momentary switches N°1
4	S2 _NO	NO Contact Relay n°2
5	S2 _C	Common relay contact n°2
6	E2_NUM_PLUS	Plus digital input for momentary switches N°2
7	S3_NO	NO Contact Relay n°3
8	S3_C	Common relay contact n°3
9	E3_NUM_PLUS	Plus digital input for momentary switches N°3
10	S4_NO	NO Contact Relay n°4
11	S4_C	Common relay contact n°4
12	E4_NUM_PLUS	Plus digital input for momentary switches N°4
13	S5_NO	NO Contact Relay n°5
14	S5_C	Common relay contact n°5
15	E5_NUM_PLUS	Plus digital input for momentary switches N°5
16	S6_NO	NO Contact Relay n°6
17	S6_C	Common relay contact n°6
18	E6_NUM_PLUS	Plus digital input for momentary switches N°6
19	+ BAT	Power supply input 8-32VDC
20	CODING	Coding input
21	MASS	Battery mass



### Terms and conditions

The manufacturer cannot be held responsible and accepts no responsibility in the event of harm to persons or property due to improper use and in reference to the warnings provided in this manual.

SCHEIBER reserves the right to change the characteristics of its products in the interest of its customers. The manual supplied with this product must not be reproduced, transmitted, stored in a search system or translated into any language, in full or in part, by any means, without the prior written consent of SCHEIBER.

Although every effort has been made to provide you full and accurate information in this manual we ask that you inform the SCHEIBER representative of your country in case of any error or omission we may have overlooked.

SCHEIBER reserves the right to change the characteristics of the hardware and software described in these manuals at any time and without prior notice.

### Warranty terms & after-sales

### **WARRANTY SUBJECT:**

The company SCHEIBER warranties all its products' range against failures or masked-failures according to the article 1641 and followings

of the Civil Code. Repairs and replacement of the equipment during the warranty period do not change terms or time of this warranty which is of 2 years. Repairs and replacement of the faulty parts under warranty are made only on presentation of the invoice which certifies the warranty beginning date.

#### **WARRANTY DOES NOT APPLY:**

This warranty can not be applied in case of misuse, wrong installation, repair by anyone else than a SCHEIBER authorised technician, damage arising from improper use (fuses replaced by another value), utilisation in an unsuitable environment or if the equipment has suffered from physical damages through handling, transport. It does not cover calibration or verification due to the normal age of the components. Warranty modalities: The equipment freight will be charged to the customer. If the returned equipment is not conform, our company considers it has the right to refuse the free repair and proposes an estimate.

### **RESPONSIBILITY LIMITS:**

In any case, the company SCHEIBER will not be held responsible for direct damages or damages not due to the normal use of the equipment. In case of a dispute arising between the parties, the case shall be submitted to the French Right to the court specified by the company SCHEIBER.



## **Question?**

contact@scheiber.fr





**Problem?** 

sav@scheiber.fr

85120 • Saint-Pierre du Chemin

**2 Bellevue**, Phone: +33 (0)2 51 51 73 21

sav@scheiber.fr France www.scheiber.fr